LIMITED 3 YEAR WARRANTY

Assembly Instructions

Thank you for purchasing the Universal Backrest by TACO Marine. Since 1959, we have taken great pride in offering the highest-quality products with excellent customer service. We stand behind our products 100 percent. Please visit our website **tacomarine.com** for more detailed information on a wide variety of products and to register your new accessory for warranty.

FOR TACO MARINE LEANING POSTS

1. Search for the eight pre-drilled holes by feeling for them on the non-cushion / marine lumber side of the back rest. Mark the cloth when a hole is discovered.

2. Align the holes on the round pads of the swivel arms with the marks made on the cloth.

3. Install the eight machine screws that are provided - four screws for left arm and four screws for the right arm. Place a screw through the hole of the round pad located at the end of the swivel arms and fasten each screw onto the pre-drilled holes of the marine lumber.

4. Once the left and right swivel arms are installed onto the backrest, the swivel arms will align with the two outer-most rod holders on the TACO Marine Leaning Post. When not in use, the swivel arms may be folded in for the convenience of storage.

   NOTE: If mounting in areas with no pre-drilled holes, please use the provided wood screws instead of the machine screws.

FOR OTHER LEANING POSTS

1. Take measurements to suit the backrest. Measure the distance between the two rod holders where you plan to place the right and left swivel arms of backrest.

2. Follow steps 3 - 4 above.

Box Includes

- **8 MACHINE SCREWS (A):** 1/4" DIAMETER , 1" LONG, WITH A 20 THREAD COUNT (TO BE USED WHEN DESIRED MOUNTING IS OUTER POSITION IN PRE- DRILLED HOLES)

- **8 WOOD SCREWS (B):** 1/4" DIAMETER , 1" LONG, WITH A 10 THREAD COUNT (TO BE USED WHEN DESIRED MOUNTING IS INNER POSITION)

A   **B**

⚠️ **WARNING:**

@tacomarine
f 📷 ▶